



Compaq ProLiant Storage System /U

User Guide

First Edition (November 1997)
Part Number 304147-001
Compaq Computer Corporation



COMPAQ COMPUTER CORPORATION SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN, NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS MATERIAL. THIS INFORMATION IS PROVIDED "AS IS" AND COMPAQ COMPUTER CORPORATION DISCLAIMS ANY WARRANTIES, EXPRESS, IMPLIED OR STATUTORY AND EXPRESSLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, GOOD TITLE AND AGAINST INFRINGEMENT.

Compaq ProLiant Storage System /U User Guide

Contents

About This Guide

How this Guide is Arranged	ix
Symbols in Text.....	x
Product Safety Information	x
Symbols on Equipment	x
Rack Stability	xi
Getting Help	xii

Chapter 1

Introduction to the Compaq ProLiant Storage System /U

Features	1-3
Front Panel Features	1-4
Rear Panel Features	1-5
Contents of Kit	1-6
Hot-Pluggability	1-7
Hot-Pluggable Drives	1-8
Maximum Storage	1-8
SCSI Controllers.....	1-9
SCSI ID Assignments	1-9
Model U1 (Single Bus).....	1-10
Model U2 (Dual Bus).....	1-11
Features Supported by your Operating System	1-11
System Power	1-14
Options	1-15
Redundant Power Supply Option	1-15
Recovery Server Option	1-15
Dual Bus Conversion.....	1-16
Single Bus Conversion	1-17

Chapter 2

Installation of ProLiant Storage System /U

Materials Needed	2-1
Installing the ProLiant Storage System /U	2-2
Installing Options	2-2
Choosing a Location.....	2-2
Installing the Storage System	2-3
Installing the Hot-Pluggable Hard Drives	2-9
Installing the SCSI Controller	2-11
Cabling	2-12
Connecting the Power	2-16
Configuring the ProLiant Storage System /U	2-17
Rack Warnings and Precautions	2-21
The Optimum Environment.....	2-22
Space Requirements	2-22
Power Requirements.....	2-22
Grounding	2-23
Temperature Requirements	2-24
Airflow Requirements	2-25
Blanking Panels	2-25

Chapter 3

Operation

Powering up the System	3-1
Status Indicators	3-1
Front Panel	3-2
Power Supply	3-3
Fan Array Module	3-4
Recovery Server I/O Board	3-5
Disk Drives.....	3-6

Chapter 4

Troubleshooting

Using the Status Indicators	4-1
Disk Drives.....	4-1
Fan Array Module	4-2
Power Supply	4-3
Replacing Components.....	4-4
Disk Drives.....	4-4
Power Supply	4-9
Fan Array.....	4-13
I/O Board.....	4-15

Chapter 5

Installing Options

Redundant Power Supply	5-1
Option Kit Contents.....	5-1
Additional Materials Needed.....	5-1
Preparing the Storage System.....	5-2
Installation.....	5-3
Recovery Server	5-5
Option Kit Contents.....	5-5
Additional Materials Needed.....	5-5
Preparing the Storage System.....	5-5
Installation.....	5-6
Dual Bus Conversion.....	5-8
Option Kit Contents.....	5-8
Additional Materials Needed.....	5-8
Preparing the Storage System.....	5-8
Installation.....	5-9

Single Bus Conversion	5-13
Option Kit Contents.....	5-13
Additional Materials Needed.....	5-13
Preparing the Storage System.....	5-13
Installation.....	5-14

Appendix A

Regulatory Compliance Notices

Federal Communications Commission Notice	A-1
Class A Equipment.....	A-1
Class B Equipment	A-2
Modifications	A-2
Cables	A-2
Declaration of Conformity, United States Only	A-3
Canadian Notice (Avis Canadien)	A-3
Class A Equipment.....	A-3
Class B Equipment	A-3
European Union Notice	A-4
Japanese Notice	A-4
Regulatory Compliance Label	A-5

Appendix B

Electrostatic Discharge

Preventing Electrostatic Damage.....	B-1
Grounding Methods.....	B-2

Appendix C

Specifications

ProLiant Storage System /U	C-1
Rack-Mountable ProLiant Storage System /U	C-2

Appendix D

Power Cord Set Requirements

General Requirements	D-1
Country-Specific Requirements	D-2

Appendix E

Getting Help

Compaq Web Site	E-1
Telephone Numbers	E-1

Index

About This Guide

This User Guide provides information about the installation and configuration of the Compaq ProLiant Storage System /U.

How this Guide is Arranged

This User Guide is designed to be used as step-by-step instructions for new system installation or as a reference for troubleshooting or future upgrades.

Chapter 1 - *Introduction*

This section provides an introduction to the features of the ProLiant Storage System /U. It also contains other general information relating to the ProLiant Storage System /U that may be useful during planning or installation.

Chapter 2 - *Installation*

This section provides the information you will need to install and configure your new ProLiant Storage System /U.

Chapter 3 - *Operation*

This section contains information about the actual operation of the ProLiant Storage System /U that you may encounter during normal day-to-day use.

Chapter 4 - *Troubleshooting*

This section contains high-level troubleshooting information and component replacement procedures for the ProLiant Storage System /U.

Chapter 5 - *Installing Options*

This section provides step-by-step instructions for the installation of any of the upgrade options available for ProLiant Storage System /U.

NOTE: This User Guide contains configuration and upgrade information that will prove valuable in the future. If you are installing the ProLiant Storage System /U but will not be the end user, please pass this guide on to the person who will be responsible for the unit when you have completed the storage system installation.

Symbols in Text

These symbols may be found in the text of this guide. They have the following meanings.



WARNING: Indicates that failure to follow directions in the warning could result in bodily harm or loss of life.



CAUTION: Indicates that failure to follow directions could result in damage to equipment or loss of information.

IMPORTANT: Presents clarifying information or specific instructions.

NOTE: Presents commentary, sidelights, or interesting points of information.

Product Safety Information

Symbols on Equipment

These icons may be located on equipment in areas where hazardous conditions may exist.



Any surface or area of the equipment marked with these symbols indicates the presence of electrical shock hazards. Enclosed area contains no operator serviceable parts.

WARNING: To reduce the risk of injury from electrical shock hazards, do not open this enclosure.



Any RJ-45 receptacle marked with these symbols indicates a Network Interface Connection.

WARNING: To reduce the risk of electrical shock, fire, or damage to the equipment, do not plug telephone or telecommunications connectors into this receptacle.



Any surface or area of the equipment marked with these symbols indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists.

WARNING: To reduce the risk of injury from a hot component, allow the surface to cool before touching.



Power Supplies or Systems marked with these symbols indicate the equipment is supplied by multiple sources of power.



WARNING: To reduce the risk of injury from electrical shock, remove all power cords to completely disconnect power from the system.

Rack Stability



WARNING: To reduce the risk of personal injury, always ensure that the rack is adequately stabilized before extending a component outside the rack. Extend only one component at a time. The rack may become unstable if more than one component is extended for any reason.

Getting Help

Although this guide has been designed to provide all the information that you should normally need to install the ProLiant Storage System /U, you may find that you require additional help. Appendix E contains telephone numbers and web access information to assist you in getting additional help. Use this information if you:

- encounter a problem during installation
- require help performing the procedures in this User Guide
- need to order a cable or other part from Compaq

See Appendix E for the telephone number of your nearest Compaq Reseller or Authorized Service Provider. The Compaq web site is a good place to get the latest operating system drivers and other information that could help you get the most from your new Compaq ProLiant Storage System /U.

Chapter 1

Introduction to the Compaq ProLiant Storage System /U

The Compaq ProLiant Storage System /U is a high-performance external Wide-Ultra SCSI-3 storage system for hot-pluggable disk drives. It is available in two models, ProLiant Storage System U1 (single bus) and ProLiant Storage System U2 (dual bus). Either model is available in tower or rack configurations. Available options provide increased system fault-tolerance protection.




Figure 1-1. Compaq ProLiant Storage System /U

.....

1-2 *Introduction to the ProLiant Storage System /U*




Figure 1-2. Rack-Mountable ProLiant Storage System /U

Features

The following features apply to the ProLiant Storage System /U:

Form Factors:	Tower 19-inch rack	
Models:		
ProLiant Storage System U1	Single bus	
ProLiant Storage System U2	Dual bus	
Maximum Number of Drives:	1-inch	1.6-inch
ProLiant Storage System U1	7	7
ProLiant Storage System U2	12	8
Disk Drive Interface:	Fast-SCSI-2, Fast-Wide SCSI-2, or Wide-Ultra SCSI-3	
SCSI ID Select:	Automatic	
Options:	Redundant Power Supply Recovery Server Single bus to dual bus conversion kit Dual bus to single bus conversion kit	
Hot-Pluggable Components:	Drives Fan Array Power Supply (in redundant power supply configurations)	
Status Indicators:	Storage system front panel Fan Array Power Supply Recovery Server I/O (optional)	
Internal Cabling Changes for Reconfiguration:	None	
Warranty:	Three-years parts and labor On-site where available	

Front Panel Features

Figure 1-3 shows the front panel controls accessible to the user. The rack model has the status indicators and power switch, but no plastic door.




Figure 1-3. Front panel features (tower model shown)

Rear Panel Features

Figure 1-4 shows the features and accessible components on the ProLiant Storage System /U rear panel.




Figure 1-4. Rear panel features (ProLiant Storage System Model U1 shown)



CAUTION: In a single power supply configuration, make certain that the Redundant Power Supply Cover Plate remains in place to maintain thermal integrity within the storage system.

Contents of Kit

The ProLiant Storage System /U kit contains the following items:




Figure 1-5. Contents of the ProLiant Storage System /U kit

Hot-Pluggability

Hot-pluggability refers to the ability to remove and replace a component without interfering with system operation. There are three components in a ProLiant Storage System /U system that are considered hot-pluggable:

- **Drives** - Failed hot-pluggable drives in fault-tolerant configurations can be replaced without interrupting system operation. The data on the failed drive will be automatically restored on the replacement drive.
- **Fan array** - If one of the cooling fans in the storage system should fail (status indicator is amber), the entire fan array can be replaced without interrupting system operation.
- **Power supply** - In systems with the optional redundant power supply installed, either power supply may be removed and replaced without interrupting system operation.

See Chapter 4 for specific limitations when replacing hot-pluggable components. It is important to understand that the hot-pluggability features must also be supported by the operating system, and in the case of the drives, the SCSI controller. See Table 1-2.

Hot-Pluggable Drives

The ProLiant Storage System /U supports these Compaq hot-pluggable drives:

- 1.6-inch Fast SCSI-2
- 1.6-inch Fast-Wide SCSI-2
- 1.6-inch Wide-Ultra SCSI-3
- 1.6-inch Wide-Ultra SCSI-3 10,000 RPM Drive
- 1-inch Fast-SCSI-2
- 1-inch Fast-Wide SCSI-2
- 1-inch Wide-Ultra SCSI-3

ProLiant Storage System /U will accept both 1-inch and 1.6-inch standard height drives. The drives may be of any storage capacity but must be mounted on Compaq hot-pluggable drive trays.

In ProLiant Storage Systems U2 (dual bus) models, SCSI IDs are automatically assigned according to the drive location, allowing 1-inch and 1.6-inch drives to be easily intermixed. However, to make the maximum use of storage space, use 1-inch drives for up to six drives per bus.

Maximum Storage

The maximum number of drives that may be installed in ProLiant Storage System /U is shown in Table 1-1 below.

Table 1-1
Maximum Number of Drives

Drive Tray Height	Model U1	Model U2
1 inch	7	12 (6 on each bus)
1.6 inch	7	8 (4 on each bus)

SCSI Controllers

ProLiant Storage System /U may be connected to any Fast-Wide SCSI-2 or Wide-Ultra SCSI controller with appropriate external wide SCSI cables. Supported Compaq SCSI controllers include:

- 32-Bit Fast-Wide SCSI-2 Controller
- Wide-Ultra SCSI-3 Controller
- SMART-2 Array Controller Family

SCSI ID Assignments

Each device on a SCSI bus must have a unique identification number in the range of 0 to 6. The SCSI ID determines the device priority when attempting to use the SCSI bus. The highest priority, SCSI ID 7, is reserved for the controller.

SCSI IDs are automatically assigned in the storage system according to the drive bay used for each drive. The SCSI ID for each bay is indicated on the front panel for both single and dual bus systems.



CAUTION: Server lockups could occur if a hard drive is installed in a drive bay set with a SCSI ID that is already used by another device in the server if both devices are on the same SCSI bus.

IMPORTANT: All SCSI hard drives on the same SCSI bus must be either internal (within the server) or in an external storage system, but not both. A configuration with both internal and external SCSI hard drives requires more than one SCSI bus.

Model U1 (Single Bus)

The SCSI IDs assigned to drive bays in the ProLiant Storage System Model U1 (single bus) are shown below.




Figure 1-6. SCSI ID numbers in the ProLiant Storage System Model U1

Model U2 (Dual Bus)

The SCSI IDs assigned to drive bays in the ProLiant Storage System Model U2 (dual bus) are shown below.




Figure 1-7. SCSI ID numbers in the ProLiant Storage System Model U2

Features Supported by your Operating System

You can use the ProLiant Storage System /U with a variety of SCSI controllers, drives, and operating systems. Most operational features of the storage system, beyond simple data storage, depend on the combination of SCSI controller and operating systems listed in Table 1-2. Before setting up your equipment, you should review the supported features for your configuration.

Table 1-2
Features Supported With These Operating Systems and Controllers**

SCSI Controller	NetWare	Windows NT	SCO UNIX	OS/2	Banyan
SMART-2 Array Controller Family	RAID-0	RAID-0	RAID-0	RAID-4	RAID-1
	RAID-1	RAID-1	RAID-1	RAID-5	RAID-4
	RAID-4	RAID-4	RAID-4	Duplexing	RAID-5
	RAID-5	RAID-5	RAID-5	Hot-plug drives	Hot-plug p/s
	Duplexing	Duplexing	Duplexing	Hot-plug p/s	Hot-plug fans
	Hot-plug drives	Hot-plug drives	Hot-plug drives	Hot-plug fans	Indicators
	Hot-plug p/s	Hot-plug p/s	Hot-plug p/s	Indicators	
Wide-Ultra SCSI -3 Controller	Hot-plug fans	Hot-plug fans	Hot-plug fans		
	Indicators	Indicators	Indicators		
32-Bit Fast-Wide SCSI-2 or Integrated 32-Bit Fast-Wide SCSI-2	RAID-0	RAID-0	Hot-plug drives*		
	RAID-1	RAID-1	Hot-plug p/s		
	Hot-plug drives	RAID-5	Hot-plug fans		
	Hot-plug p/s	Hot-plug drives	Indicators		
32-Bit Fast-SCSI-2 or Integrated 32-Bit Fast-SCSI-2	Hot-plug fans	Hot-plug p/s			
	Indicators	Hot-plug fans			
		Indicators			
Two 32-Bit Fast-Wide SCSI-2 or Two 32-Bit Fast-SCSI-2	RAID-0	RAID-0	Hot-plug drives*		
	RAID-1	RAID-1	Hot-plug p/s		
	Duplexing	RAID-5	Hot-plug fans		
	Hot-plug drives	Duplexing	Indicators		
Two Wide-Ultra SCSI -3 Controllers	Hot-plug p/s	Hot-plug drives			
	Hot-plug fans	Hot-plug p/s			
	Indicators	Hot-plug fans			

* Several software products are available that support SCO UNIX for data striping, data mirroring, and fault tolerance.

** See Table 1-3 for definition of terms

Table 1-3
Key to Table 1-2 Terminology

Term	Definition
RAID-0	Non-fault tolerant data striping
RAID-1	Data mirroring with data striping
RAID-4	Data guarding
RAID-5	Distributed data guarding
Duplexing	Mirrored drives attached to independent buses or controllers
Hot-plug drives	Disk drives can be installed or removed without powering down the system
Hot-plug fans	Fan array module can be removed and installed without powering down the system
Hot-plug p/s	Redundant power supply can be removed and replaced without powering down the system
Indicators	Status indicators on hot-pluggable components and front panel are supported

System Power

The system power in the ProLiant Storage System /U does not completely shut off with the power switch. The two positions of the front panel power switch should be considered as ON and STANDBY, rather than ON and OFF. The STANDBY position removes power from most of the electronics and the drives but portions of the power supply and some internal circuitry remain active.

To completely remove all power from the system, you must disconnect the power cord from the storage system. In systems with multiple power supplies, you must disconnect all the power cords to completely remove power from the system.



WARNING: To reduce the risk of electrical shock or damage to the equipment, disconnect power from the storage system by unplugging all power cords from either the electrical outlet or the storage system.

Options

The following options are available for your ProLiant Storage System /U and may be obtained from your local Compaq Reseller or Authorized Compaq Service Provider.

Redundant Power Supply Option

ProLiant Storage System /U has provisions for adding a second power supply that acts as a redundant supply when installed. The Redundant Power Supply is identical to the primary supply and when installed, shares the electrical load equally. If either supply should fail or be removed, the other will take over the full load without interruption. Hot-pluggability permits replacing the failed supply without bringing the system down.

The Redundant Power Supply can be installed by the user at any time by simply plugging it in to the storage system. No tools are needed and there is no need to bring the system down. See Chapter 5, “Installing Options” for more information on installing and using this option.

Recovery Server Option

Recovery Server refers to a fault-tolerant technique where two independent servers have access to the same stored data. Both servers are connected to separate Wide-Ultra SCSI-3 ports on the storage system, but only one port has access to the internal SCSI bus at a time. If the primary server should fail, the Recovery Server option will automatically switch the storage system internal SCSI bus connection to the secondary server. The secondary server will then take over all functions of the system without loss of data. Both Online and Backup recovery techniques are supported and all hardware, software, instructions, and cabling are included in the kit. The Recovery Server Option can only be used in ProLiant Storage System U1 (single bus) models.

The Recovery Server Option can be installed by the user by simply replacing the standard I/O Board with the Recovery Server I/O Board. No tools are required and there is no need to access internal cabling or circuitry. See Chapter 5, “Installing Options” for more information on installing and using this option.

Dual Bus Conversion

The Dual Bus Conversion option is offered for customers who find that their Model U1 storage system now requires two SCSI buses. Dual Bus refers to dividing the total storage space in the ProLiant Storage System Model U1 into two separate storage areas, each with its own SCSI bus. This may be used:

- as part of a fault-tolerant configuration (controller duplexing).
- to make maximum use of the available storage space with up to 12 drives instead of 7 with a single SCSI bus.
- as separate storage areas for two servers.

This option effectively converts the ProLiant Storage System Model U1 into a Model U2. The available storage space is split into two Wide-Ultra SCSI-3 buses with four 1.6-inch drives or six 1-inch drives on each bus. Each bus is totally independent and requires a separate Fast-Wide SCSI-2 or Wide-Ultra SCSI-3 controller and cable. Dual Bus Conversion option cannot be used with the Recovery Server option.

The Dual Bus Option can be installed by the user by replacing the Single Bus I/O Board with the Dual Bus I/O Board and replacing the Single Bus drive cage with a Dual Bus drive cage. See Chapter 5, “Installing Options” for more information on installing and using this option.

Single Bus Conversion

The Single Bus Conversion option is offered for customers who find that they no longer require two SCSI buses and want to convert it to a Model U1 single bus system. This option provides the ProLiant Storage System Model U2 with a single Wide-Ultra SCSI-3 bus that supports up to seven 1.6-inch or 1-inch drives, effectively converting the unit to a Model U1. This may be used:

- when the storage system is no longer part of a duplexed drive array.
- when the storage space is no longer shared between two servers.
- to make maximum use of the available storage space with a single SCSI bus.

The Single Bus Option can be installed by the user by replacing the Dual Bus I/O Board with the Single Bus I/O Board and replacing the Dual Bus drive cage with a Single Bus drive cage. See Chapter 5, “Installing Options” for more information on installing and using this option.

Chapter 2

Installation of ProLiant Storage System /U

Use the information in this chapter to install and configure your new ProLiant Storage System /U or Rack-Mountable ProLiant Storage System /U.

Because of the similarities between the tower and rack-mountable models of ProLiant Storage System /U, most of this information will apply to both models. To avoid repetition, these instructions will generally be directed to the tower model of the storage system. Where the differences are important, specific instructions will be given for each model.

Materials Needed

To install the ProLiant Storage System /U you will need these materials:

- ProLiant Storage System /U or Rack-Mountable ProLiant Storage System /U
- Rack mounting hardware (Rack-Mountable ProLiant Storage System /U only)
 - Left and right mounting brackets (supplied)
 - Mounting screws and cage nuts (supplied)
 - #2 Phillips screwdriver (not supplied)
- Hot-pluggable drive(s)
- Any options you are going to install, for example
 - Recovery Server option
 - Redundant power supply option
- AC power cord (supplied)
- External SCSI cable (supplied)

Installing the ProLiant Storage System /U

To install the ProLiant Storage System /U you will need to perform these steps:

1. Install any options in the storage system
2. Choose a location
3. Install the ProLiant Storage System /U unit
4. Install the hot-pluggable drive(s)
5. Install the SCSI controller(s) in a server (if required)
6. Cable the units together
7. Configure the system

Installing Options

Although it is not difficult to install options at any time, it may be easier to do so now, before the storage system is placed in its final location. See Chapter 5 in this guide for complete instructions on the installation of each option. Installation instructions are also included with each option.

Choosing a Location

Choose an installation site with the following features:

Tower Systems

- A sturdy, level surface, preferably on or near the floor
- At least 8 inches (20 cm) of clearance at the front of the storage system for access to the hot-pluggable drives
- At least 12 inches (30.5 cm) of clearance at the back of the storage system for proper ventilation, cable access, and maintenance access to replaceable components
- A grounded electrical outlet that is easily accessible and located as near the storage system as possible



WARNING: To avoid injury or equipment damage, the mounting brackets must be level. If the brackets are not level, the Rack-Mountable ProLiant Storage System /U cannot be installed correctly.

To be sure of the correct mounting position:

- ❑ Use the tick-marks as a reference. Each tick-mark (a small dimple on the edge of the vertical mounting rails) is one “U” or 1.75 inches. The markings on the template will match the tick-marks on the rear mounting rails when the alignment is correct.
- ❑ Use the number of holes between the bottom of the rack and the mounting brackets as a reference.




Figure 2-1. Measuring with the template

3. Install the cage nuts in the marked locations on the front and rear vertical mounting rails in the rack cabinet.




Figure 2-2. Installing the cage nuts

4. Identify the front of the right and left mounting brackets. The tabs help align the bracket for correct mounting position.




Figure 2-3. Mounting brackets with alignment tabs

5. Attach the brackets to the front mounting rails with two screws provided. Tighten the screws securely.




Figure 2-4. Attaching the brackets to the front mounting rails

6. Attach the brackets to the rear mounting rails with two screws provided. Tighten the screws securely.




Figure 2-5. Attaching the brackets to the rear mounting rails

7. Place the Rack-Mountable ProLiant Storage System /U on the mounting brackets and slide it fully into the rack.




Figure 2-6. Installing Rack-Mountable ProLiant Storage System /U into the rack

8. Secure the storage system in the rack with the two thumbscrews in the corners of the front panel.

Installing the Hot-Pluggable Hard Drives

To install the drives into the storage system:

1. Open the front door (tower storage system only).
2. Choose the bay location (SCSI ID) of the drive.
 - ❑ In Model U1 (single bus) systems, it is recommended that drives be installed beginning at SCSI ID 0 (bottom or left bay).
 - ❑ In Model U2 (dual bus) systems, installation is usually dictated by the fault-tolerant data protection technique being used. Consult the reference documentation for your data protection scheme to determine which SCSI bus each drive is to use.
3. Refer to the markings on storage system front panel to find the correct location of the drive tray. Markings for 1.6-inch drives are on the left (top in rack systems), while 1-inch drives are on the right (bottom). The 1-inch and 1.6-inch drives may be intermixed as long as they conform to the appropriate front panel markings. Note that in model U2 (dual bus) systems some SCSI IDs are not available with 1.6-inch drives.

4. Install the drive as shown below.
 - a. Fully open both latches on the drive tray and insert the drive into the correct drive bay.




Figure 2-7. Opening the latches

- b. Slide the drive into the bay as far as it will go.




Figure 2-8. Sliding the drive tray into the storage system

- c. Close both latches against the front of the drive until they snap into place. Levers on each latch should catch behind the metal lip of the bay, drawing the drive into position and securing it in place.




Figure 2-9. Latching the drive into place

IMPORTANT: After installing, pull on the drive to see if the tray is properly seated. If you are able to remove the drive without releasing the latches, open the latches all the way and try again to seat the drive, ensuring that the levers engage the front panel and pull the drive into position.

Installing the SCSI Controller

If a SCSI controller is required, install it in the server now. ProLiant Storage System /U is supported by a variety of Fast-Wide SCSI-2 and Wide-Ultra SCSI-3 controllers and array controllers (see Chapter 1). Use the installation instructions provided with the server or controller.

Cabling

Cabling requirements vary depending on the system configuration. See your specific system configuration below for cabling instructions.

Rack-Mountable Systems

To ensure that the cabling in the back of a rack system does not interfere with system operation or maintenance, follow these suggestions for cable management on those systems. See Figure 2-10.

This configuration will allow removal of either hot-pluggable power supply in redundant power supply systems without disturbing system operation. With the cables out of the way, status indicators will be easily visible.

- All cables, including SCSI and power, for each storage system should be bundled together along the plane of the top of the system. Use one or more cable ties to hold the cables together securely at the back of the unit.
- All cables should run through the cable channel on the left side of the rack.
- Tie the cable bundle securely to the cable channel to relieve the stress on the connectors at the back of the storage system.




Figure 2-10. Cable management in a Rack-Mountable ProLiant Storage System /U

Model U1

See Figure 2-11 for an illustration of SCSI cable connections for Model U1 (single bus) systems.




Figure 2-11. SCSI cable connections for Model U1 systems

Model U2

See Figure 2-12 for an illustration of SCSI cable connections for Model U2 (dual bus) systems.




Figure 2-12. SCSI cable connections for Model U2 systems

Recovery Server Systems

See Figure 2-13 for an illustration of cable connections in a Recovery Server installation. For more detailed explanations of this type of system, refer to the *Recovery Server Option User Guide* that is supplied in the Recovery Server Option Kit.




Figure 2-13. Cable connections in Recovery Server systems

Connecting the Power

After all hardware components are installed and the unit is in place the power may be connected.

1. Plug the AC power cord into the ProLiant Storage System /U. The power supply automatically senses the input voltage so that it is not necessary to select the correct main voltage.




Figure 2-14. Connecting the power cord



WARNING: To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded electrical outlet that is easily accessible at all times.
- Disconnect power from the storage system by unplugging all power cords from either the electrical outlet or storage system.

2. Plug the power cord into a nearby grounded outlet.
3. If a redundant power supply option has been installed, plug its AC power cord into the power supply and then into a grounded outlet.

4. Turn ON the power to the storage system, using the power switch on the front panel. (The power-on process may take up to 10 seconds to complete. Wait until the power-on indicator turns green before proceeding to Step 5.)
5. Turn ON the power to the server(s).

Configuring the ProLiant Storage System /U

The Compaq System Configuration Utility is used to:

- Verify the SCSI controller configuration
- Verify that the SCSI IDs of the new hard drives are recognized and configured for your system

The Compaq System Configuration Utility is included on the Compaq SmartStart and Support Software CD supplied with the new ProLiant Storage System /U. This utility may be run:

- Directly from the boot hard drive of the controlling server
- Directly from the SmartStart and Support Software CD
- From diskettes created from the SmartStart and Support Software CD

Each of these methods is explained below.

From Hard Drive

Use these instructions to run the Compaq System Configuration Utility if your server has had this utility previously installed in the Systems partition on the boot drive.

1. Boot the server normally.
2. Press F10 when the white square cursor is in the upper right-hand corner of the screen. (Be prepared; this cursor is only present for about 2 seconds during boot.)
3. Select the menu items to configure the hardware.
4. Select *Review hardware settings*.

Rack Warnings and Precautions

Before performing any procedure with a rack-mounted product, be sure you understand the following warnings and precautions:



WARNING: To reduce the risk of personal injury, always ensure that the rack is adequately stabilized before extending a component outside the rack. A rack may become unstable if more than one component is extended for any reason. Extend only one component at a time.



WARNING: To reduce the risk of personal injury or damage to the equipment, be sure that:

- The leveling jacks are extended to the floor.
- The full weight of the rack rests on the leveling jacks.
- The stabilizers are attached to the rack if it is a single rack installation.
- The racks are coupled together in multiple rack installations.

The Optimum Environment

When installing your ProLiant Storage System /U in a rack, certain standards of temperature and power requirements must be met.

Space Requirements

The following spatial needs should be considered when deciding where to install your rack:

- Clearance in the front of the rack should be a minimum of 25 inches for the front door to open all the way and for adequate airflow.
- Clearance in the back of the rack should be a minimum of 30 inches to allow for servicing and for adequate airflow.
- To service the power supply, allow 15 inches of side clearance.

Power Requirements



WARNING: To reduce the risk of personal injury, fire, or damage to the equipment, do not overload the AC supply branch circuit that provides power to the rack. Consult the electrical authority having jurisdiction over your facility wiring and installation requirements.

- The power load needs to be balanced between available AC supply branch circuits.
- The overall system AC current load must not exceed 80 percent of the branch circuit AC current rating.
- If power strips are used, the load should not exceed 80 percent of the power strip's marked electrical current rating.

The installation of this equipment shall be in accordance with Local/Regional electrical regulations governing the installation of Information Technology Equipment by licensed electricians. This equipment is designed to operate in installations covered by the National Electric Code (ANSI/NFPA 70, 1993) and the code for Protection of Electronic Computer/Data Processing Equipment (NFPA-75, 1992).

For electrical power ratings on options, refer to the product's rating label or user documentation supplied with that option.

Grounding

For proper operation and safety, this equipment is required to be properly grounded in accordance with NFPA 70-1993, Article 250. All power distribution devices, branch wiring, and receptacles must be "Listed" grounding type devices.

When using power strips for electrical distribution, ensure that ground integrity is maintained for each connection made. Plug each component into a reliably grounded outlet.

Temperature Requirements

To ensure continued safe and reliable operation of the equipment, locate the system in a well-ventilated, climate-controlled environment.

The Compaq Maximum Recommended Ambient Operating Temperature (Tmra) for most server products is 35°C (95°F). Therefore, the temperature in the room where the rack is located should not exceed 35°C (95°F).

The operating temperature inside the rack will always be higher than the room temperature, and is dependent on the configuration of equipment in your rack. The Tmra for each piece of equipment should be checked before installation.

The maximum internal rack temperature for your configuration should not exceed the values in the following table:

Table 2-1 Rack Internal Temperature Maximums	
Equipment Included	Maximum Internal Rack Temperature
Rack-Mountable ProLiant Servers	50°C/122°F
Compaq Rack-Mountable options	40°C/104°F
Other manufacturers' options	See other manufacturers' specifications



CAUTION: To reduce the risk of damage to the equipment when installing third-party options:

- Ensure that the option equipment does not impede airflow to the Rack-Mountable ProLiant Servers or increase the internal rack temperature beyond the Compaq specified maximum rating.
- Ensure that the Manufacturer's Maximum Recommended Ambient Operating Temperature of the option equipment is not exceeded when installed in the rack.

Airflow Requirements

Compaq ProLiant rackmount servers draw cool air in through the front door and exhaust warm air out the rear. Therefore, the front door of the rack must be adequately ventilated to allow ambient room air to enter the cabinet, and the rear door must be adequately ventilated to allow the warm air to escape from the cabinet. Do not block the ventilation apertures.



CAUTION: If a third-party rack is used, the following minimum requirements should be observed to ensure adequate airflow and to prevent damage to the equipment:

Front: The front must have a minimum of 25 inches of unrestricted ventilation.

Side: The clearance between the installed module and the side panels of the rack should be a minimum of 2.75 inches.

Rear: The clearance between the back of the rack and the wall should be a minimum of 30 inches, and the equipment should be operating without a rear door.

Blanking Panels

If all of the vertical space in the rack is not filled by components, the gaps that are left will cause a change in airflow through the rack and across the components. These gaps need to be covered with blanking panels.

Chapter 3

Operation

This section describes the operational features of the Compaq ProLiant Storage System /U.

Powering up the System

Turn ON the ProLiant Storage System /U before turning on the server (or servers) connected to storage system. Any drives in the storage system must be available when the server controlling them is powered up. This is especially important on systems using fault-tolerant data protection schemes.

The ProLiant Storage System /U is powered up with the power switch in the upper left corner of the front panel (upper right on rack systems).

NOTE: Allow a few seconds for the power-on routine to complete and the Power indicator to turn green before using the storage system.

Status Indicators

The ProLiant Storage System /U system is equipped with a series of status indicators located on strategic components. These indicators, with the exception of those on the front panel, are related only to the individual component.

Front Panel

These indicators apply to the complete storage system.




Figure 3-1. Front panel status indicators

Table 3-1
Front Panel Status Indicators

Indicator	Condition	Meaning
Power	Green	System power ON
	Off	System in STANDBY* or system power has been removed
Fault	Amber	Fault detected in one or more sub-systems
	Off	No faults detected

* The system power in the ProLiant Storage System /U does not completely shut off with the power switch. STANDBY removes power from most of the electronics and the drives, but portions of the power supply and some internal circuitry remain active.

Power Supply

These indicators apply only to the power supply on which they are located.




Figure 3-2. Power supply status indicators

Table 3-2
Power Supply Status Indicator

Indicator	Condition	Meaning
Status	Amber	Fault detected: Caused by the second power supply or something else in the system.
	Amber flashing	Failed self-test
	Green/Amber alternating	Power supply: <ul style="list-style-type: none"> ● failed to restart after a prolonged fault, or ● is not installed correctly. Check for damaged connector pins and reinstall.
	Green flashing	Power supply will restart within 20 seconds
AC Power	Green	AC power is connected to this power supply
	Off	No AC power connected to this supply

NOTE: Flashing indicators during the power-up process is normal.

Fan Array Module

This indicator applies only to the fan array module.




Figure 3-3. Fan array module status indicator

Table 3-3
Fan Array Module Status Indicator

Indicator	Condition	Meaning
Status	Green	Fans running normally
	Amber	Fault detected in one or more fans
	Off	No power connected to fan array module

Recovery Server I/O Board

These indicators apply to only the Recovery Server I/O option board.




Figure 3-4. Recovery Server I/O board status indicators

Table 3-4
Recovery Server I/O Board Status Indicators

Indicator	Condition	Meaning
Server 1	Green	Server 1 is connected to the drives
	Off	Server 1 is not connected to the drives
Server 2	Green	Server 2 is connected to the drives
	Off	Server 2 is not connected to the drives

Disk Drives

These indicators apply only to the disk drive on which they are located.







Figure 3-5. Drive status indicators

Table 3-5
Drive Status Indicators

Indicator	Condition	Meaning
 Online	Green	Drive is configured and recognized by the controller
	Flashing	Volume reconstruction or expansion is under way DO NOT REMOVE THE DRIVE
	Off	Drive is inactive
 Drive Access	Green	Drive is being accessed by the controller
	Off	Drive is not being accessed
 Drive Failure	Amber	Drive has failed and may be replaced
	Off	Drive has not failed

Chapter 4

Troubleshooting

This chapter contains troubleshooting procedures and suggestions that should be followed to diagnose problems quickly and minimize the impact on system operation.

Using the Status Indicators

If the fault indicator on the front panel is amber, or if Compaq Insight Manager indicates a fault, immediately determine the reason for this alert. Examine the component status indicators to see if any of them are indicating a fault.

Disk Drives

Look for an amber Drive Failure indicator on any hot-pluggable drive tray.




Figure 4-1. Drive Failure indicator

If any Drive Failure indicator is amber, replace that drive as soon as possible. See “Replacing Components” later in this chapter for important information on when it is safe to replace drives. Failure to observe these instructions can result in loss of data.

Fan Array Module

Check to see if the status indicator on the fan array module is amber.




Figure 4-2. Fan status indicator

If this indicator is amber, replace the fan module as soon as possible. See “Replacing Components” later in this chapter for important information on how to replace this module. Failure to observe these instructions can result in component damage.



CAUTION: Do not allow the system to operate for more than two minutes without a working fan module in place. Operation longer than this with no forced air cooling, especially in systems with a full complement of drives, may permanently damage the drives or electronics in the storage system and result in data loss.

If you will be hot-plugging the fan array module, be sure to have everything ready before you begin the procedure, which should normally take no more than one minute.

Power Supply

Check to see if the status indicator on the standard or redundant (if so equipped) power supply is amber.




Figure 4-3. Power supply status indicator



CAUTION: In a single power supply configuration, as shown in Figure 4-3, the lower power supply cover plate must be kept in place for thermal integrity. This is the cover plate located below the Fan array.

If this indicator is amber, flashing amber, or alternating green/amber, replace the power supply as soon as possible. See “Replacing Components” later in this chapter for important information on how to replace the power supply. Failure to observe these instructions can result in loss of data.

If the status and power indicators are both OFF on one supply of a redundant power supply system, check the AC power source to the supply. Redundant operation is not assured and failure to observe these instructions can result in loss of data.

Replacing Components

It is important to follow these instructions when replacing components in the ProLiant Storage System /U. If done improperly, it is possible to lose data or damage equipment.

Disk Drives

If you must replace a hot-pluggable drive, it is important that you follow these guidelines.

- If the drive is NOT part of a fault tolerant system, you may replace the drive with the storage system powered ON or OFF.
- If the drive is part of a fault tolerant data protection system, you must replace the drive only when the storage system power is ON and the *Online* and *Drive Access* indicators are OFF.



CAUTION: Failure to observe these conditions when replacing a failed drive in a fault-tolerant configuration may result in data loss.

Figure 4-4 (following) illustrates the conditions when you may or may not remove a drive in a fault-tolerant system.




Figure 4-4. Hot-pluggable drive replacement conditions

To replace a drive:

1. Be sure that the On-line and Drive Access indicators are both OFF. See Figure 4-4.
2. Squeeze the latches and pivot the ejector levers to the full open position.




Figure 4-5. Opening the drive tray latches

3. Pull the drive out of the storage system drive cage.

4. Open the latches fully on the replacement drive and insert it into the same bay as the drive just removed, sliding it in as far as it will go.




Figure 4-6. Inserting the drive

5. Close both latches against the front of the drive until they snap into place. Levers on each latch should catch behind the metal lip at the front of the bay drawing the drive into position and securing it in place.




Figure 4-7. Latching the drive into place

The drive tray indicators will light one at a time and then turn off together to indicate that the system has recognized the new drive. In fault-tolerant configurations allow the replacement drive to be reconstructed automatically with data from the other drives. While reconstruction is taking place, the On-line indicator will flash.

Power Supply

The power supply in the ProLiant Storage System /U is pluggable. This means that the supply may be easily replaced by simply unplugging it and plugging in a replacement. Select the procedure to follow depending on whether or not the system has a redundant power supply option installed.



WARNING: To reduce the risk of injury or damage to the equipment, observe the following precautions when connecting and disconnecting power to the power supplies:

- Install the power supply before connecting the power cord to the power supply.
- Unplug the power cord before removing the power supply from the equipment.
- To completely remove power from a system, unplug all power cords from the power supplies.

Single Power Supply Systems

The procedure to replace a power supply in a ProLiant Storage System /U with a single power supply is as follows:

1. Perform a normal system shutdown for the server(s) supporting the storage system.
2. Turn OFF the server, then place the storage system in STANDBY (front panel power switch).
3. Shut off power or remove the AC power cord from the power supply before replacing it.

- Depress the catch on the power supply handle and pivot the handle open to release the power supply. Pull the supply from the chassis.




Figure 4-8. Removing the power supply

5. With the handle fully open, insert the replacement supply into the opening and slide it in along the rails as far as it will go.

NOTE: If any resistance is felt when inserting the power supply, it may be necessary to wiggle the supply slightly (side to side) to slide it in place.

6. Pivot the handle closed until it snaps into place. This will secure the power supply in the chassis.




Figure 4-9. Installing the power supply

7. Plug the power cord in the power supply and turn ON the storage system.
8. Turn ON the server(s) supporting the storage system.

The status indicator on the power supply, as well as the fault indicator on the front panel, should now be green, indicating that the new supply and the storage system is fully operational.

Redundant Power Supply Systems

In a ProLiant Storage System /U with the Redundant Power Supply option installed, there are two identical power supplies. If either supply is faulty, an amber light indicates that a fault exists. An amber indicator does not always indicate the bad supply. Either power supply may be replaced with the storage system power on without affecting normal system operation.

1. Unplug the power cord from the failed supply. If the system is running, be careful not to disturb the power cord for the other power supply.
2. Depress the catch on the power supply handle and pivot the handle open to release the power supply. Pull the supply from the chassis. See Figure 4-8.



CAUTION: Do not operate the ProLiant Storage System /U for extended periods of time with either power supply location open. Internal cooling air flow will be disrupted without a power supply or blank cover installed in both locations. This could cause overheating of internal components and possible data loss. In Redundant Power Supply systems, retain the blank cover for reuse in case it is necessary to remove one of the supplies.

3. With the handle fully open, insert the replacement supply into the opening and slide it in along the rails as far as it will go.
4. Pivot the handle closed until it snaps into place. This will secure the power supply in the chassis. See Figure 4-9.
5. Plug the power cord in the new supply.

The status indicators on both supplies as well as the fault indicator on the front panel should now be green, indicating that power supply redundancy has been restored.

Fan Array

If the status indicator on the fan module is amber, a problem has been detected in at least one of the three fans in the array. The entire module is hot-pluggable and can be replaced without affecting normal system operation.



CAUTION: Do not allow the system to operate for more than two minutes without a working fan module in place. Operation longer than this with no forced air cooling, especially in systems with a full complement of drives, may permanently damage the drives or electronics in the storage system and result in data loss.

If you will be hot-plugging the fan array module, be sure to have everything ready before you begin the procedure, which should normally take no more than one minute.

1. Loosen the two thumbscrews securing the fan module to the chassis.
2. Remove the fan module by pulling it straight out of the chassis.




Figure 4-10. Removing the fan module

3. Install the replacement fan module by sliding it into the opening along the tracks as far as it will go, making sure that the connectors mate.

- Secure the module in place by tightening the two thumbscrews.





Figure 4-11. Installing the fan module

The three fans should start turning immediately. The status indicator on the fan module as well as the fault indicator on the front panel should now be green, indicating a fully functional fan array.

I/O Board

The storage system must be powered down before the I/O board may be replaced. This procedure is the same for all three I/O boards (Single Bus, Dual Bus, or Recovery Server).

1. Perform a normal system shutdown.
2. Turn OFF the server(s) supporting the storage system, then place the storage system in **STANDBY** (front panel power switch).



WARNING: To avoid risk of injury from electrical shock, remove all power cords to completely disconnect power from the system.

3. Remove the power cord(s) from the outlet and then from each power supply.
4. Remove the SCSI cable(s) from the I/O board. In dual-bus and Recovery Server systems, note the destination (Bus 1 or Bus 2) of each cable.
5. Squeeze the latches and pivot open the two ejector levers securing the I/O board in place.

6. Remove the I/O board by pulling it straight out of the chassis.




Figure 4-12. Removing the I/O board

7. Install the replacement I/O board by inserting it into the tracks in the opening in the ProLiant Storage System /U rear panel.

-

[illegible]

Chapter 5

Installing Options

ProLiant Storage System /U supports these optional features:

- Redundant Power Supply
- Recovery Server
- Dual Bus Conversion
- Single Bus Conversion

This chapter provides the instructions for installing these options in ProLiant Storage System /U.

Redundant Power Supply

The Redundant Power Supply option provides a second power supply to supplement the standard supply so that one will always be on-line.

Option Kit Contents

- Redundant Power Supply
- AC power cord
- Fast-Wide SCSI cable (for use with the Wide-Ultra SCSI-3 Controller board)
- Redundant Power Supply Quick Installation Instructions

Additional Materials Needed

- None

Preparing the Storage System

Because this is a hot-pluggable option it is not necessary to power down the storage system. However, be sure to observe these precautions:



WARNING: To reduce the risk of injury or damage to the equipment, observe the following guidelines when connecting and disconnecting power to the power supplies:

- Install the power supply before connecting the power cord to the power supply.
 - Unplug the power cord before removing the power supply from the equipment.
-



CAUTION: Do not move a working storage system. This could cause disk errors, damage to disk drives, and possible loss of data.



CAUTION: Be careful when working around the power and SCSI cables on the back of a working storage system. Accidentally disconnecting a cable could cause loss of data.



CAUTION: Do not operate the ProLiant Storage System /U for extended periods of time with either power supply location open. Internal cooling air flow will be disrupted without a power supply or blank cover installed in both locations. This could cause overheating of internal components and possible data loss. In Redundant Power Supply systems, retain the blank power supply cover for reuse in case it is necessary to remove one of the supplies.

Installation

Perform the following steps to install the Redundant Power Supply option in a ProLiant Storage System /U.

1. Loosen the thumbscrew securing the blank panel over the lower power supply opening and remove the panel.




Figure 5-1. Removing the blank power supply panel

IMPORTANT: Remove the protective cover from the power supply connector.

2. Depress the latch and pivot the handle on the Redundant Power Supply to the fully open position.
3. Align the power supply with the rail in the power supply opening and push the supply in as far as it will go.

4. Pivot the handle closed until it latches into place. This will secure the supply in the chassis.




Figure 5-2. Installing the Redundant Power Supply



WARNING: To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
- Plug the power cord into a grounded electrical outlet that is easily accessible at all times.
- Disconnect power from the storage system by unplugging all power cords from either the electrical outlet or storage system.

5. Plug the new AC power cord into the Redundant Power Supply and then into a grounded AC outlet.

The power indicator on the Redundant Power Supply will be green, indicating that there is AC power available to the new supply. The status indicator on each supply will also be green, indicating that no fault is detected. When the status indicators on both power supplies are green, the storage system is protected against power supply failure.

This completes the installation of the Redundant Power Supply option.

Recovery Server

The Recovery Server option provides SCSI connections to two independent servers.

Option Kit Contents

- Recovery Server I/O board
- Recovery Server Option User Guide and Warranty Card
- Fast-Wide SCSI Cable (for use with the Wide-Ultra SCSI-3 controller board)
- Smart Start and Support Software CD
- Cable

Additional Materials Needed


- None

Preparing the Storage System

Perform the following steps to prepare the ProLiant Storage System /U for installation of the Recovery Server option.

1. Back up all data on all drives in the storage system before beginning the installation procedure.
2. Perform a normal system shutdown.
3. Turn OFF the server supporting the storage system.
4. Place the storage system in STANDBY.

5. Disconnect the SCSI cable from the storage system.



WARNING: To avoid risk of injury from electrical shock, remove all power cords to completely disconnect power from the system.

6. Disconnect the power cord(s) from the ProLiant Storage System /U.c

Installation

Perform the following steps to install the Recovery Server option in a ProLiant Storage System /U.

1. Squeeze the latches and pivot open the two ejector levers securing the Single Bus I/O board in the rear of the ProLiant Storage System /U. See Figure 5-3.
2. Pull the I/O board straight out of the storage system.




Figure 5-3. Removing the Single Bus I/O board

.....

3. Align the Recovery Server I/O board in the opening and slide it forward in the rails as far as it will go with the latches fully open.
4. Close the latches against the rear panel until they snap into place. Levers on each latch should catch behind the metal lip drawing the board into position and securing it in place.




Figure 5-4. Installing the optional Recovery Server I/O board

5. Replace the AC power cord(s).

This completes the hardware installation of the Recovery Server Option. Refer to the *Recovery Server Option User Guide* furnished in this option kit for information on connecting the ProLiant Storage System /U to the servers in one of several configurations.

Dual Bus Conversion

The Dual Bus Conversion option kit converts a Model U1 storage system to a storage system with two SCSI buses. This option provides a hot-pluggable drive backplane and an I/O board that supports two independent Wide-Ultra SCSI-3 buses and converts the system to a Model U2.

Option Kit Contents

- Dual Bus drive cage
- Dual Bus I/O board
- Dual Bus Quick Installation Instructions
- SCSI cable for the second SCSI bus
- Hardware for tower and rack configurations
- Model and serial labels

Additional Materials Needed

- Torx T-15 screwdriver
- Compaq System Configuration Utility
- Compaq Array Configuration Utility (arrayed systems only)

Preparing the Storage System

Perform the following steps to prepare the ProLiant Storage System /U for installation of the Dual Bus Conversion option.

1. Back up all data on all drives in the storage system before beginning the installation procedure.
2. Perform a normal system shutdown.
3. Turn OFF the server supporting the storage system.
4. Place the storage system in STANDBY.
5. Disconnect the SCSI cable from the storage system.
6. Disconnect the power cord(s) from the storage system.

Installation

Perform the following steps to install the Dual Bus Conversion option in a ProLiant Storage System /U.

1. Remove all the drives and blank drive panels.
2. Loosen or remove the power supply(s).
3. Loosen or remove the fan module.
4. Remove the Single Bus I/O board.





Figure 5-5. Removing the modules from the rear of the ProLiant Storage System /U

5. Tower system:

- Open the front door and remove it by lifting up.
- Remove the 12 screws marked with a  securing the front panel to the chassis
- Carefully slide the drive cage from the chassis.





Figure 5-6. Removing the drive cage from a tower system

Rack system:

- a. Loosen the two thumbscrews securing the system in the rack.
- b. Remove the 8 screws marked with a  securing the front panel to the chassis. The chassis will slide free from the rack.
- c. Carefully slide the drive cage out of the chassis. The removal of the drive cage is best performed outside of the rack.




Figure 5-7. Removing the drive cage from the rack system

6. Select and install the correct front panel.
7. Carefully slide the Dual Bus drive cage into the chassis as far as it will go. The drive cage is properly seated when the front panel is flush with the front of the chassis and the screw holes are aligned.

IMPORTANT: There are two alignment pins on the back and two capture fingers on the side (bottom in rack units) of the drive cage which must engage corresponding features on the chassis. It may be necessary to “wiggle” the drive cage slightly in order to properly seat it in the chassis. The units will mate easily when properly aligned. Do not force the two units together if there is obvious resistance.

8. Tower system:

- Replace the 12 screws to secure the front panel to the chassis.
- Place the serial label on the drive cage and the model label on the front panel so that they cover the old labels.
- Replace the front door.

Rack system:

- Replace the 8 screws to secure the front panel to the chassis.
- Place the serial label on the drive cage and the model label on the front panel so that they cover the old labels.
- Tighten the two thumbscrews to secure the storage system in the rack.

9. Install the new Dual Bus I/O board supplied in the option kit.
10. Replace the fan module.
11. Replace the power supply(s).
12. Replace the power cord(s).
13. Install the drives and blank drive panels in the appropriate locations.
14. Connect the Bus 1 port on the Dual Bus I/O board to SCSI controller 1 using the SCSI cable provided.
15. Connect the Bus 2 port on the Dual Bus I/O board to SCSI controller 2 using the SCSI cable provided.
16. Turn ON the storage system.
17. Turn ON the server(s) supporting the storage system.
18. Run the Compaq System Configuration Utility to recognize the new drive configuration.
19. Run the Compaq Array Configuration Utility (if appropriate) to configure the drives into an array.
20. Place the Single Bus drive cage, I/O board, and Quick Installation Instructions in the Dual Bus options shipping container to save and protect them for possible future use.

Installation of the Dual Bus Conversion option is complete.

Single Bus Conversion

The Single Bus Conversion option is offered for customers who want to convert to a Model U1 single bus system. This option provides a drive cage for seven hot-pluggable drives and I/O board that supports a single Wide-Ultra SCSI-3 bus and essentially converts the system to a Model U1.

Option Kit Contents

- Single Bus drive cage
- Single Bus I/O board
- Single Bus Quick Installation Instructions
- Hardware for tower and rack configurations
- Model and serial labels

Additional Materials Needed

- Torx T-15 screwdriver
- Compaq System Configuration Utility
- Compaq Array Configuration Utility (arrayed systems only)

Preparing the Storage System

Perform the following steps to prepare the ProLiant Storage System /U for installation of the Single Bus option.

1. Back up all data on all drives in the storage system before beginning the installation procedure.
2. Perform a normal system shutdown.
3. Turn OFF the server supporting the storage system.
4. Place the storage system in STANDBY.
5. Disconnect the SCSI cables from the storage system.
6. Disconnect the power cord(s) from the storage system.

Installation

Perform the following steps to install the Single Bus option in a ProLiant Storage System /U.

1. Remove all the drives and blank drive panels.
2. Loosen or remove the power supply(s).
3. Loosen or remove the fan module.
4. Remove the Dual Bus I/O board.





Figure 5-8. Removing the modules from the rear of the ProLiant Storage System /U

5. Tower system:
 - a. Open the front door and remove it by lifting up.
 - b. Remove the 12 screws marked with a  securing the front panel to the chassis
 - c. Carefully slide the drive cage from the chassis.





Figure 5-9. Removing the drive cage from a tower system

Rack system:

- a. Loosen the two thumbscrews securing the system in the rack.
- b. Carefully slide the chassis out of the rack.
- c. Remove the 8 screws marked with a  securing the front panel to the chassis.
- d. Carefully slide the drive cage from the chassis.




Figure 5-10. Removing the drive cage from a rack system

6. The option kit contains new front panels for both the rack (two piece) and tower (single piece) models of the storage system. Remove the existing front panel and select and install the correct new front panel.
7. Carefully slide the Single Bus drive cage into the chassis as far as it will go. The drive cage is properly seated when the front panel is flush with the front of the chassis and the screw holes are aligned.

IMPORTANT: There are two alignment pins on the back and two capture fingers on the side (bottom in rack units) of the drive cage which must engage corresponding features on the chassis. It may be necessary to "wiggle" the drive cage slightly in order to properly seat it in the chassis. The units will mate easily when properly aligned. Do not force the two units together if there is obvious resistance.

8. Tower system:

- Replace the 12 screws to secure the front panel to the chassis.
- Place the serial label on the drive cage and the model label on the front panel so that they cover the old labels.
- Replace the front door.

Rack system:

- Replace the 8 screws to secure the front panel to the chassis.
- Place the serial label on the drive cage and the model label on the front panel so that they cover the old labels.
- Tighten the two thumbscrews to secure the storage system in the rack.

9. Install the new Single Bus I/O board supplied in the option kit.
10. Replace the fan module.
11. Replace the power supply(s).
12. Replace the power cord(s).
13. Install the drives and blank drive panels in the appropriate locations.
14. Connect the SCSI Bus port on the Single Bus I/O board to the SCSI controller using the SCSI cable provided.
15. Turn ON the storage system.
16. Turn ON the server supporting the storage system.
17. Run the Compaq System Configuration Utility to recognize the new drive configuration.
18. Place the Dual Bus drive cage, I/O board, and Quick Installation Instructions in the Single Bus option shipping container to save and protect them for possible future use.

Installation of the Single Bus Conversion option is complete.

Appendix A

Regulatory Compliance Notices

Federal Communications Commission Notice

Part 15 of the Federal Communications Commission (FCC) Rules and Regulations has established Radio Frequency (RF) emission limits to provide an interference-free radio frequency spectrum. Many electronic devices, including computers, generate RF energy incidental to their intended function and are, therefore, covered by these rules. These rules place computers and related peripheral devices into two classes, A and B, depending upon their intended installation. Class A devices are those that may reasonably be expected to be installed in a business or commercial environment. Class B devices are those that may reasonably be expected to be installed in a residential environment (i.e., personal computers). The FCC requires devices in both classes to bear a label indicating the interference potential of the device as well as additional operating instructions for the user.

The rating label on the device shows which class (A or B) the equipment falls into. Class B devices have an FCC ID on the label. Class A devices do not have an FCC ID on the label. Once the class of the device is determined, refer to the following corresponding statement.

Class A Equipment

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at personal expense.

Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Compaq Computer Corporation may void the user's authority to operate the equipment.

Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods in order to maintain compliance with FCC Rules and Regulations.

Declaration of Conformity, United States Only

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For questions regarding this declaration, contact:

Compaq Computer Corporation
P. O. Box 692000, Mail Stop 510101
Houston, Texas 77269-2000

Or call (281) 514-3333

To identify this product, refer to the Series number found on the product.

Canadian Notice (Avis Canadien)

Class A Equipment

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Class B Equipment

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Union Notice

Products with the CE Marking comply with both the EMC Directive (89/336/EEC) and the Low Voltage Directive (73/23/EEC) issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Norms (in brackets are the equivalent international standards):

- EN55022 (CISPR 22) - Electromagnetic Interference
- EN50082-1 (IEC801-2, IEC801-3, IEC801-4) - Electromagnetic Immunity
- EN60950 (IEC950) - Product Safety

Japanese Notice

お使いになっている装置にVCCIマークが付いていましたら、次の説明文をお読み下さい。

この装置は、第二種情報装置（住宅地域又はその隣接した地域において使用されるべき情報装置）で住宅地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会（VCCI）基準に適合しております。しかし、本装置をラジオ、テレビジョン受信機に近接してご使用になると、受信障害の原因となることがあります。取扱説明書に従って正しい取り扱いをして下さい。

VCCIマークが付いていない場合には、次の点にご注意下さい。

この装置は、商工業地域で使用するべき第一種情報装置です。住宅地域又はその隣接した地域で使用するするとラジオ、テレビジョン受信機等に受信障害を与えることがあります。

Regulatory Compliance Label

The label showing regulatory compliance information is located inside the fan compartment in the rear of the chassis. To gain access to this label remove the Fan Array module.



CAUTION: See Chapter 4 in this guide for important information about removing the Fan Array. Failure to observe these instructions could result in permanent damage to this equipment.




Figure A-1. Location of regulatory compliance label

A-6 Regulatory Compliance Notices



Figure A-2. Sample regulatory compliance label

Appendix B

A discharge of static electricity from a finger or other conductor may damage printed circuit boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

Preventing Electrostatic Damage

To prevent electrostatic damage, observe the following precautions:

- Avoid hand contact by transporting and storing parts in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free work stations.
- Place parts on a grounded surface before removing them from their container.
- Avoid touching pins, leads, or circuitry.
- Make sure you are properly grounded when touching a static-sensitive component or assembly.

Grounding Methods

There are several methods for grounding. Use one or more of the following measures when handling or installing electrostatic-sensitive parts:

- Use a wrist strap connected by a ground cord to a grounded workstation or the computer chassis. Wrist straps are flexible straps with a minimum of 1 megohm +/- 10 percent resistance in the ground cords.
- Use heel straps, toe straps, or bootstraps at standing workstations. Wear the straps on both feet when standing on conductive floors or dissipating floor mats.
- Use conductive field service tools.
- Use a portable field service kit with a folding static-dissipating work mat.

If you do not have any of the suggested equipment for proper grounding, have an Authorized Compaq Service Provider install the part.

NOTE: For additional information on static electricity, or assistance with the installation of this product, contact your Authorized Compaq Service Provider or refer to the Maintenance and Service Guide.

Appendix C Specifications

This appendix provides operating and physical specifications for the Compaq ProLiant Storage System /U and Rack-Mountable ProLiant Storage System /U.

ProLiant Storage System /U

Table C-1
ProLiant Storage System /U Specifications

Parameter	English	Metric
Dimensions (including foot)		
Height	20.5 in	52.0 cm
Depth	25.0 in	63.5 cm
Width	10.8 in	27.4 cm
Weight		
No drives installed, single power supply	50 lb	22.7 kg
Input Power Requirements		
Rated Input Voltage	100 to 240 VAC	100 to 240 VAC
Rated Input Frequency	50 - 60 Hz	50 - 60 Hz
Rated Input Current	6 A	6 A
Input Power (max)	592 W*	592 W*
Heat Dissipation (max)	2021 Btu/hr*	2021 Btu/hr*
Temperature Range		
Operating	50° to 95° F	10° to 35° C
Shipping	-22° to 122° F	-30° to 50° C
Relative Humidity (noncondensing)		
Operating	8% to 90%	8% to 90%
Nonoperating	5% to 95%	5% to 95%
Maximum Wet Bulb Temperature	101.7° F	38.7° C

* Input Power and Heat Dissipation specifications are maximum values and apply to worst-case conditions at full rated power supply load. The power/heat dissipation for your installation will vary depending on the equipment configuration.

Rack-Mountable ProLiant Storage System /U

Table C-2
Rack-Mountable ProLiant Storage System /U Specifications

Parameter	English	Metric
Dimensions		
Height	6.9 in	17.5 cm
Depth	22.9 in	58.2 cm
Width	19.0 in	48.3 cm
Weight		
No drives installed, single power supply	34 lb	15.5 kg
Input Power Requirements		
Rated Input Voltage	100 to 240 VAC	100 to 240 VAC
Rated Input Frequency	50 - 60 Hz	50 - 60 Hz
Rated Input Current	6 A	6 A
Input Power (max)	592 W*	592 W*
Heat Dissipation (max)	2021 Btu/hr*	2021 Btu/hr*
Temperature Range		
Operating	50° to 95° F	10° to 35° C
Shipping	-22° to 122° F	-30° to 50° C
Relative Humidity (noncondensing)		
Operating	8% to 90%	8% to 90%
Nonoperating	5% to 95%	5% to 95%
Maximum Wet Bulb Temperature	101.7° F	38.7° C

* Input Power and Heat Dissipation specifications are maximum values and apply to worst-case conditions at full rated power supply load. The power/heat dissipation for your installation will vary depending on the equipment configuration.

Appendix D

Power Cord Set Requirements

The power cord set meets the requirements for use in the country where you purchased your equipment. The voltage selection switch allows you to select the appropriate line voltage for your server.

Power cord sets for use in other countries must meet the requirements of the country where you use the server. For more information on power cord set requirements, contact your Authorized Compaq Dealer.

General Requirements

The requirements listed below are applicable to all countries:

- The length of the power cord must be at least 6.0 feet (1.8 m) and a maximum of 12 feet (3.7 m).
- The power cord set must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord will be used.
- The power cord set must have a minimum current capacity and nominal voltage rating of 10 A/125 volts AC, or 10A/250 volts AC, as required by each country's power system.
- The appliance coupler must meet the mechanical configuration of an EN60320/IEC 320 Standard Sheet C13 Connector, for mating with the appliance outlet on the computer.

Country-Specific Requirements

Use the following table to identify the appropriate accredited agency in your country.

Table D-1 Power Cord Set Requirements - By Country		
Country	Accredited Agency	Applicable Note Numbers
Australia	EANSW	1
Austria	OVE	1
Belgium	CEBC	1
Canada	CSA	2
Denmark	DEMKO	1
Finland	SETI	1
France	UTE	1
Germany	VDE	1
Italy	IMQ	1
Japan	JIS	3
Norway	NEMKO	1
Sweden	SEMKO	1
Switzerland	SEV	1
United Kingdom	BSI	1
United States	UL	2

Notes:

1. Flexible cord must be <HAR> Type HO5VV-F, 3-conductor, 1.0 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. Flexible cord must be Type SVT or equivalent, No. 18 AWG, 3-conductor. Wall plug must be a two-pole grounding type with a NEMA 5-15P (15A, 125V).
3. Appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 1.0 mm² conductor size. Wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7A, 125V) configuration.

Appendix E Getting Help

If you have a problem and have exhausted the information in this guide, you can get further information and other help in the following locations.

Compaq Web Site

The Compaq Web Site has information on this product as well as the latest drivers and Flash ROM images. You can access the Compaq Web Site by logging on to the Internet at <http://www.compaq.com>.

Telephone Numbers

Contact your nearest Compaq Authorized Reseller or Service Provider for more information.

- For the name of your nearest Compaq Authorized Reseller:
 - In the United States, call 1-800-345-1518
 - In Canada, call 1-800-263-5868
- For Compaq technical support:
 - In the United States and Canada, call 1-800-386-2172
 - Elsewhere, call one of the numbers listed below

Compaq Worldwide Technical Support Telephone Numbers		
Location	Voice	FAX
APD	65-7503030	65-7504909
Argentina	54-1 313 3100	54-1 313 3100 Ext 21
Australia	61-2-9911-1955	61-2-9911-1900
Austria	0222-87816-16	0222-87816-82
Bahrain	973-210-214	
Belgium	(02) 716-96-96	(02) 725-22-13
Brazil	55 11 5505-3600	55 11 5505-3922 Ext 4336
Canada	1-800-386-2172	
Caribbean	1-800-345-1518	
Central America	281-378-2206	

Continued

.....

Compaq Worldwide Technical Support Telephone Numbers Continued

Location	Voice	FAX
Chile	562-274-3007	
China	86-10-834-6721	86-10-834-6713
Colombia	571-345-0266	571-312-0157
Czech Republic	42-2-232-8772	42-2-232-8773
Denmark	45-90-4545	45-90-4595
Equador	593-2504540	
Europe/Middle East/Africa	(49) 089-9933-2891	
Finland	9800-206-720 (+358-800-1-206720)	90-6155-9899 (+358-0-61559899
France	(33 1) 41-33-4455	(33 1) 41-33-4263
Germany	0180-5-212111	089-9933-3399
Hong Kong	852-90116633	852-28671734
Hungary	36-1-201-8776	36-1-201-9696
India	(91-80) 559-6023	
Italy	392-57-90300	392-575-00686
Japan	0120-101589	+81 3-5402-5959
Korea	82-2-523-3575	82-2-3471-0321
Malaysia	(603) 718-1636	
Mexico	(525) 229-7910	(525) 229-7988
Netherlands	06-91681616	06-8991116
New Zealand	649-307-3969	
Norway	22-072-020	22-072-021
Poland	48-2-630-3535	48-2-630-3553
Portugal	351-1-4120132	351-1-4120654
Singapore	65-7503030	65-7504909
South Africa	+27-11-728-6999	+27-11-728-3335
Spain	341-640-1302	341-640-0124
Sweden	(46) 8 703 5240	(46) 8 703 5222
Switzerland	411 838 410/2222	01-837-0969
Taiwan	(886) 2-3761170	(886) 2-7322660
Thailand	62-2-679-6222	62-2-679-6220
United Kingdom	44-81-332-3888	44-81-332-3409
United States	1-800-386-2172	1-800-345-1518
Venezuela	(582) 953.69.44	(582) 952.86.70

Index

A

Airflow
for rack 2-25

C

Cabling
dual bus systems 2-14
rack systems 2-12
Recovery Server systems 2-15
single bus systems 2-13
Component
replacement procedures 4-4
Configuring the system 2-17
Contents of kit 1-6

D

Disk Drive
hot-pluggable 1-8
maximum storage 1-8
replacement guidelines 4-4
replacement procedures 4-6
status indicators 3-6, 4-1
troubleshooting 4-1
Dual Bus conversion option
installation 5-8
overview 1-16

F

Fan Array Module
replacement procedure 4-13
status indicator 3-4, 4-2
troubleshooting 4-2

Features 1-3
front panel 1-4
operating system supported 1-11
rear panel 1-5
Front Panel
status indicators 3-2

H

Hot-pluggability 1-7
Hot-pluggable drives 1-8
installing 2-9

I

I/O Board
replacement procedure 4-15
Icons *See* Symbols on Equipment
ID *See* SCSI ID
Indicators *See* Status Indicators
Installation
guidelines 2-2
location 2-2
materials 2-1
Installing
dual bus conversion option 5-8
hot-pluggable drives 2-9
ProLiant Storage System /U 2-1
rack systems 2-3
recovery server option 5-5
redundant power supply
option 5-1
single bus conversion
option 5-13

M

Model U1
overview 1-1
SCSI ID 1-10

overview 1-1
SCSI ID 1-11

Operating system

- supported features 1-11

- dual bus conversion 1-16
- overview 1-15
- recovery server 1-15
- redundant power supply 1-15
- single bus conversion 1-17

Power Cord Compaq ProLiant 800r

- replacement procedure 4-9
- status indicators 3-3, 4-3
- troubleshooting 4-3

- features 1-3
- front panel features 1-4
- kit contents 1-6
- model U1 overview 1-1
- model U2 overview 1-1
- rear panel features 1-5
- specifications C-1

Rack

- airflow for 2-25
safety warnings 2-21
temperature requirements
for 2-24

Recovery Server I/O Board

- status indicator 3-5

installation 5-5
overview 1-15

installation 5-1
overview 1-15

- drive 4-6
- fan array module 4-13
- I/O board 4-15
- power supply 4-9

Replacing Components 4-4

SCSI controllers

- installation 2-11
supported 1-9

```

assignments  1-9
model U1     1-10
model U2     1-11

```

installation 5-13
overview 1-17

ProLiant Storage System /U C-1
Rack-Mountable ProLiant
Storage System /U C-2

- drive 3-6, 4-1
- fan array module 3-4, 4-2
- front panel 3-2
- power supply 3-3, 4-3
- recovery server I/O board 3-5

Storage Capacity

- maximum 1-8

in text x
on equipment x

- from CD 2-18
- from diskette 2-19
- from drive 2-17

from diskette 2-19

from drive 2-17

T

- troubleshooting 4-1
- disk drives 4-1
- fan array 4-2
- power supply 4-3

disk drives 4-1

fan array 4-2

power supply 4-3